

JBR TWIN-PLUG DISTRIBUTOR ROTOR REPLACEMENT INSTRUCTIONS

1. Note how existing rotor and lower brass contact are positioned.
2. Remove two (2) 6/32 screws that secure rotor and lower brass contact to rotor platform.
3. Remove two (2) 8/32 screws that secure rotor to rotor platform.
4. Remove rotor and lower brass contact piece.
5. Install new rotor and brass contact piece.
6. Place a small amount of 242 Loctite (blue) on all four screws and reinstall.

Note: Remember you are threading these screws into a plastic rotor platform. Tighten very gently.